


# BEVERAGE FOUNTAIN

## SET-UP AND GENERAL OPERATION INSTRUCTIONS



### **WARNING!!**

#### **PLEASE READ CAREFULLY**

**DO NOT USE ANY LIQUID THAT CONTAINS PULP, SEEDS, FRUIT, RINDS** etc. This beverage fountain is designed to circulate **ONLY** clear beverages! Use of liquids containing any of the above listed items will NOT work in this beverage fountain.

NOTE: Use of ice cream or foamy punches will restrict the flow of the beverage.

1. Beverage fountain is clean and ready to use when you receive it.
2. Place beverage fountain on flat, sturdy, level surface that is near a grounded power outlet. As some splattering from fountain may occur during operation it is recommended that a clear plastic protective cover be placed directly under the beverage fountain. Protective cover should be approximately 6-8 inches larger than lower reservoir.
3. Plug beverage fountain directly into a 120 Volt **GROUND**ED power circuit.  
**DO NOT USE AN EXTENSION CORD!**
4. Pour approximately two quarts of beverage in lower reservoir and turn power switch to on. If beverage does not circulate within one minute, turn switch to off for 10 seconds. Repeat this procedure several times until beverage flows freely.
5. Turn beverage fountain off when empty.

### **CLEANUP**

After use, empty out remaining beverage and fill lower reservoir with approximately 2 gallons of warm water and turn power switch on. Let water circulate for 2-3 minutes. Empty out unit and wipe off outside surface of beverage fountain.

**WARNING! DO NOT IMMERSE BEVERAGE FOUNTAIN IN WATER!**

**!! DO NOT DISASSEMBLE BEVERAGE FOUNTAIN !!**

*Thank you for renting from*



Rents • Tents • Events

2100 South Neil • Champaign

217/356-9713