


Instructions for Using Food Chafers rented from *Herriott's*



- IMPORTANT!** Use only STERNO TYPE FUEL in the burners. (1 can of sterno type fuel per sterno holder per food chafer is supplied with each food chafer. Each can of fuel will last approximately 1 1/2 hours. Additional cans of fuel may be purchased from *Herriott's*.)
- ① NEVER light the sterno fuel before putting liquid in the water pan. Water pans should be filled to water line to insure sufficient water is contained at all times. Check frequently during use for proper water level. Refill as necessary. **DO NOT USE WITHOUT WATER!** Low flame is sufficient to maintain proper heat.
 - ② To use sterno type fuel: Pry the lid off the fuel container and set container into the sterno holder cup. Place the sterno holder cup into the sterno holder opening located on the bottom of the food chafer frame. Place the sterno holder lid on the sterno holder. Swing open sterno holder lid and light sterno fuel with a match or lighter. Adjust holder lid approximately 1/2 open. Extinguish heat by closing holder lid.
 - ③ Do not put unit on a hot stove or an open flame.
 - ④ The food pan can be placed in an oven to keep food hot.

E-Z Cleanup:

Before returning food chafer, scrape and wash food pan. Wash chafer frame and water pan in lukewarm water and mild detergent. **NEVER USE HARSH ABRASIVES.** Return food chafer(s) complete and **ALL** parts clean to avoid additional charges.



Food chafer carriers **ARE NOT** to be used for trash receptacles. Food chafer **MUST** be returned in carrier.

Thank you for renting from

Herriott's
Rents • Tents • Events

2100 S Neil • Champaign 217/356-9713