



# LAPEL MIC

## OPERATION INSTRUCTIONS

1. Before setting up Lapel Mic for operation be sure that the Liberty Sound System is set up according to instructions provided with the system. Make sure "Wireless Volume Control" is turned completely to the left (which is the Minimum Volume setting). Extend the wireless receiving antenna located on the top of the Liberty System by gently pulling the antenna straight upward. DO NOT OVEREXTEND. Turn the Liberty System ON.
2. If a battery is not pre-installed in the lapel belt pack do so by following battery replacement instructions shown to the right. Once battery is installed, if unit is to be used immediately slide Lapel Mic transmitter "POWER" switch located next to battery to "ON" position. See Fig 2
3. While speaking into the lapel mic turn Liberty Wireless volume control up gradually until desired volume level is reached.
4. Using the Mic Clip clip the lapel mic onto your clothing as high as possible in a vertical line with the mouth. This is only a suggested position. Experiment with positioning to receive optimum response. Next clip belt pack onto clothing belt.
5. The Mic/Antenna wire between the lapel mic and the belt pack also serves as the Transmit Antenna. DO NOT roll up, coil or shorten during use. This wire should be kept as straight as possible.
6. To MUTE lapel mic - turn Audio On switch (shown in figure 1 above) to OFF position.



**Battery Level Meter**  
This set of 3 multicolor LEDs indicates relative battery power, indicating whether the installed battery is low (red), mid (yellow) or high (green) strength. One or more of these will light when Lapel pack is turned on. When all 3 are lit, the battery is at maximum strength. When only the red "low" indicator lights - battery needs to be replaced.



**TO REPLACE BATTERY**  
Turn Audio to OFF; Press gently inwards on the two indents on the left and right sides of the transmitter in order to open the battery door to gain access to the Power on-off switch and the battery. Turn Power switch to Off. Remove battery (if one is present) & insert new battery in holder. (Use ONLY a 9 Volt Duracell Alkaline battery. Any other battery WILL NOT work.) Watch carefully +/- polarity. If unit is to be used immediately turn Power switch On.


7. When finished turn lapel mic and Liberty Sound System OFF to conserve battery power. Gently push the wireless receiving antenna back down into the top of the Liberty Sound System

**CAUTION: Be aware of feedback when you walk in front of Liberty unit while using a wireless microphone.**

# HANDHELD MIC

## OPERATION INSTRUCTIONS

1. Before setting up Handheld Mic for operation be sure that the Liberty Sound System is set up according to instructions provided with the system. Make sure "Wireless Volume Control" is turned completely to the left (which is the Minimum Volume setting). Extend the wireless receiving antenna located on the top of the Liberty System by gently pulling the antenna straight upward. DO NOT OVEREXTEND. Turn the Liberty System ON.
2. If a battery is not pre-installed in the Handheld Mic do so by following battery replacement instructions shown to the left. Once battery is installed, slide handheld mic "POWER" switch to "ON" position. Slide "MUTE" switch to "OFF" position.
3. While speaking into the handheld mic turn Liberty Wireless volume control up gradually until desired volume level is reached.
4. "Mute" switch cuts off the audio without completely shutting off the mic. This allows user to turn off the audio part of the Mic without allowing interference or noise to pass through the receiver.



**TO REPLACE BATTERY:** Turn Mic OFF; Slide open battery cover. Remove battery & insert new battery in holder (Use ONLY a 9 Volt Duracell Alkaline battery. Any other battery WILL NOT work.) Watch carefully +/- polarity. Slide battery cover closed.

5. When finished turn mic and Liberty Sound System OFF to conserve battery power. Gently push the wireless receiving antenna back down into the top of the Liberty Sound System.

*Thank you for renting from*

*Herriott's*  
Rents • Tents • Events

2100 S Neil • Champaign 217/356-9713